AMCI Frequently Asked Question

How Do I Calculate the Number of Turns Completed by a Resolver in the PLC?

The following ladder logic program can be used to keep track of the number of turns that an AMCI single turn resolver has made. In order to guarantee absolute position, two restrictions must be observed.

- 1) The resolver must not rotate while the PLC is off, or not scanning the rungs which may occur in the processors Program Mode. If the resolver rotates more that 1/2 of a turn while the PLC is off, the processor will not be able to calculate the correct position when power is reapplied. In this case, the machine will have to homed before normal operations can resume.
- 2) The resolver cannot complete more that 1/2 of a turn in one PLC scan. Your maximum speed is equal to 30 divided by your maximum scan time is seconds. For example, assume you maximum scan time is 20 milliseconds. Your resolver cannot exceed: (30/0.02) = 1500 RPM.

The ladder logic is written for Allen-Bradley PLC's. However, the code can be converted to any processor system that AMCI manufactures product for.

Memory Needed

The ladder logic requires four words of memory. The memory should be *signed integer words* as it is the most efficient and supported by all processors.

- > N7:0: Current Position. This is the position data read from the AMCI module this scan.
- **>** N7:1: Previous Position. This is the position data read from the module during the previous scan.
- ► N7:2: \triangle Position. The change in position during the scan. \triangle Position = (Current Position – Previous Position).
- **>** N7:3: Number of Turns. This is the calculated Number of Turns.

Ladder Logic

